# **CENTURY**

### READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY TO ENSURE PROPER AND SAFE INSTALLATION

- 1. WARNING: Risk of fire or electrical shock.
- 2. WARNING: Disconnect power before installing or servicing.
- 3. WARNING: All wiring to be performed per National Electrical
  - Code and local code by a qualified electrician.
- 4. Outdoor use only.
- 5. Suitable for Wet Location covered canopy.
- 6. Non-combustable surfaces only.


# **Fixture Wiring**


- 1. Fixture is equipped with a hanging tie strap to suspend fixture during installation. A small nail or screw can be installed in ceiling if no hanging point is available.
- 2. Remove four (4) screws from wiring compartment and remove cover (FIG A).
- 3. Remove knockout and make conduit connection to cover.
- Connect supply wires to fixture using appropriate wire nuts (FIG B).
  - 1.2. Connect ground wires to fixture ground (green).
  - 1.3 Connect AC common wire to fixture common (white).
  - 1.4. Connect AC line wire to fixture(s) common (black).

 After making connections, replace fixture cover and secure with provided screws. NOTE: Be sure cover fits properly and there is no interference with wiring.



This luminaire supports 0-10V dimming (control supplied by others) via the yellow (10V), purple (0-10V) or gray (neg) wires on the output side of the driver. Follow specific dimming control instructions for proper wiring.






#### **Fixture Mounting**

- 1. To mount recessed fixture, cut round or square access hole in ceiling large enough to fit back box (FIG C).
- 2. Securely mount fixture to ceiling using four (4) supplied screws and necessary anchors (supplied by installer).

FIG C

NOTE: Outer fixture dimensions can be custom ordered to fit alternate sized openings as small as 12" x 12".






# **CENTURY**

# Remote Mounted Battery Backup (RBB)

- 1. Fixtures ordered with Remote Battery Backup option are prewired from factory and come complete with 12' cable for operation with remote battery backup.
- 2. Refer to detailed battery backup installation guide for further details.



# **Surface Mount Conversion (RCS16-XX)**

- 1. Mount recessed fixture using optional surface mount conversion plate (ordered separately) .
- 2. Use (4) 3" bolts to mount fixture and plate to ceiling.

